

# Assembly instructions

## To assemble:

- 1 Open the transport case. Take the frame out of the transport case, then out of the blue bag.

Place it on the ground with the row of red hubs nearest to you.

- 2 Pull upward on center two red hubs to expand the frame.

Bring the red hubs towards each other until the frame clicks into place.

- 3 Place the frame in position

- 4 Take the magnetic rails out of the red bag. The two black pins indicate the top of the rail.

Unfold the rails and fit the three sections together, slide the bottom of the rail into the hub at the base of the frame. Place the back of the rail against the hub(s) at the middle of the structure and press until it snaps into the hub.

Raise the top of the rail above the top hub, then slide it downwards, until it fits into the hub. For rails with lights, place light on top of rail, raise the top of the rail above the top hub, then slide it downwards, until it fits into the hub.

Attach the remaining magnetic rails as instructed above.

- 5 Attach the others rails following these instructions.

## Installing the interior graphic or fabric panels:

*you can use the top of the container as a footstool.*

Take the first panel out of the carry case ; slide the corresponding slot to the panel (top) at top right and top left of the magnetic rails . Unroll the panels downwards, fit them onto the magnetic rails, the connection allows the exact fitting of the panels

Repeat these instructions for the interior panels

End panels: Curve the end panels and attach them to the pins at the top of the magnetic rails in the front and the back and then fit the panel onto the magnetic rails.

Your display is ready for business !

## To disassemble

Remove the interior panels and roll each panel graphic or fabric side out.

Place each panel in the transport case. Roll panels outward to maximize usable space in the core.

Remove, roll and place end panels in transport case. Roll panels outward to maximize usable space in the core.

Disconnect magnetic rails by raising the top rail above the hub and fold rail downward.

Detach the light and store in red light bag. Remove the middle sections by gently twist and pull the rail away from the hub. Lift the bottom portion of the rail out of the hub. Fold the rail to a single length and place it in the red bag. Remove and store the remaining rails in the same manner. To collapse the frame, push/pull the center two red hubs apart.

The frame will unlock and can now be lowered to the ground. Place the frame in the blue bag.

Place frame bag, magnetic rail bag and light bag into the case along with the fabric/graphic panels.

Place top on transport case and lock.

